option 1

TYPE OF PLAN

LENGTH

PROTECTION

DEDUCTIBLE

ROADSIDE ASSISTANCE

TOTAL

option 2

TYPE OF PLAN

LENGTH

PROTECTION

DEDUCTIBLE

ROADSIDE ASSISTANCE

TOTAL

fully insured



This brochure is a representation of the plans offered. It is intended to provide an outline of the benefits and parts coverage. Guarantee VC reserves the right to make changes at any time without notice or obligation.

Guarantee VC is Part of the

VCG Group of Companies

Canadian Owned and

Operated Since 1978.

- hassle free claims procedure
- all plans include trip interruption and car rental benefits
- service available anywhere in north america
- fast professional customer service

contact us

220 Duncan Mill Road, Suite 407, Toronto, Ontario, M3B 3J5 Phone: 1-800-268-3284 Fax: 1-800-358-7902



premium warranty plans

mechanical breakdown protection




guaranteevc.ca

canadian premium vehicle warranties

fast and hassle-free claims

for vehicles 6 model years old or newer



GVC

www.guaranteevc.ca
twitter.com/guaranteevc
facebook.com/GVCWarranty
Instagram.com/GVCWarranty

peace of mind on the road

Cars break down at the most inconvenient times and can be expensive to repair. Our claims process is fast and hassle-free, giving you the peace of mind against future repairs. Let's keep your car on the road.

typical repair costs

\$11,000 **ENGINE REPLACEMENT** DIFFERENTIAL REPAIR \$4,700 ALTERNATOR REPLACEMENT \$900 AIR CONDITIONER REPAIR \$750 \$950 FUEL PUMP REPLACEMENT \$750 $\mathsf{R}\mathsf{A}\mathsf{D}\mathsf{I}\mathsf{A}\mathsf{T}\mathsf{O}\mathsf{R}$ $\mathsf{R}\mathsf{E}\mathsf{P}\mathsf{A}\mathsf{I}\mathsf{R}$ TRANSMISSION REPLACEMENT \$6000 \$5200 LEAKING CYLINDER HEAD GASKET 4 WHEEL DRIVE TRANSFER CASE \$2000

premium warranty plans

	3 SI	5 ST	
	STAR	STAR 1	
	*	*	
covered		*	
components			
ENGINE			
HEAD GASKET	•	•	
ENGINE BLOCK	•	•	
CYLINDER HEADS	•	•	
CRANKSHAFT AND MAIN BEARINGS	•	•	
Crankshaft Gears	•	•	
CONNECTING RODS AND BEARINGS	•	•	
Camshaft and Bearings	•	•	
CAMSHAFT GEARS	•	•	
Push Rods	•	•	
PISTONS	•	•	
INTAKE AND EXHAUST VALVES	•	•	
VALVE SPRINGS AND RETAINERS	•	•	
GUIDES	•	•	
ROCKER ARM	•	•	
SHAFTS AND PIVOTS	•	•	
HARMONIC BALANCER AND PULLEY	•	•	
TIMING CHAIN	•	•	
OIL PUMP AND SHAFT	•	•	
RING GEAR	•	•	
RINGS AND PINS	•	•	
OIL SEPARATOR	•	•	
LIFTERS TURBOCHARGER AND SUPERCHARGER	•	•	
HOUSING WASTE-GATE ACTUATOR	•	•	
WASTE-GATE ACTUATOR AUTOMATIC TRANSMISSION	•	•	
WASTE-GATE ACTUATOR AUTOMATIC TRANSMISSION TORQUE CONVERTER	•	•	
WASTE-GATE ACTUATOR AUTOMATIC TRANSMISSION	•	•	
WASTE-GATE ACTUATOR AUTOMATIC TRANSMISSION TORQUE CONVERTER VALVE BODY	•	•	
WASTE-GATE ACTUATOR AUTOMATIC TRANSMISSION TORQUE CONVERTER VALVE BODY GEAR SETS	•	•	
WASTE-GATE ACTUATOR AUTOMATIC TRANSMISSION TORQUE CONVERTER VALVE BODY GEAR SETS MAIN AND INTERMEDIATE SHAFTS	•	•	
WASTE-GATE ACTUATOR AUTOMATIC TRANSMISSION TORQUE CONVERTER VALVE BODY GEAR SETS MAIN AND INTERMEDIATE SHAFTS CLUTCHES AND BANDS	•	•	
WASTE-GATE ACTUATOR AUTOMATIC TRANSMISSION TORQUE CONVERTER VALVE BODY GEAR SETS MAIN AND INTERMEDIATE SHAFTS CLUTCHES AND BANDS OIL PUMP	•	•	
WASTE-GATE ACTUATOR AUTOMATIC TRANSMISSION TORQUE CONVERTER VALVE BODY GEAR SETS MAIN AND INTERMEDIATE SHAFTS CLUTCHES AND BANDS OIL PUMP FLYWHEEL	•	•	
WASTE-GATE ACTUATOR AUTOMATIC TRANSMISSION TORQUE CONVERTER VALVE BODY GEAR SETS MAIN AND INTERMEDIATE SHAFTS CLUTCHES AND BANDS OIL PUMP FLYWHEEL RING GEAR	•	•	
WASTE-GATE ACTUATOR AUTOMATIC TRANSMISSION TORQUE CONVERTER VALVE BODY GEAR SETS MAIN AND INTERMEDIATE SHAFTS CLUTCHES AND BANDS OIL PUMP FLYWHEEL RING GEAR MANUAL TRANSMISSION	•	•	
WASTE-GATE ACTUATOR AUTOMATIC TRANSMISSION TORQUE CONVERTER VALVE BODY GEAR SETS MAIN AND INTERMEDIATE SHAFTS CLUTCHES AND BANDS OIL PUMP FLYWHEEL RING GEAR MANUAL TRANSMISSION HOUSING MAIN AND INTERMEDIATE SHAFTS GEAR SETS	•	•	
WASTE-GATE ACTUATOR AUTOMATIC TRANSMISSION TORQUE CONVERTER VALVE BODY GEAR SETS MAIN AND INTERMEDIATE SHAFTS CLUTCHES AND BANDS OIL PUMP FLYWHEEL RING GEAR MANUAL TRANSMISSION HOUSING MAIN AND INTERMEDIATE SHAFTS GEAR SETS SYNCHRONIZER RINGS	•	•	
WASTE-GATE ACTUATOR AUTOMATIC TRANSMISSION TORQUE CONVERTER VALVE BODY GEAR SETS MAIN AND INTERMEDIATE SHAFTS CLUTCHES AND BANDS OIL PUMP FLYWHEEL RING GEAR MANUAL TRANSMISSION HOUSING MAIN AND INTERMEDIATE SHAFTS GEAR SETS SYNCHRONIZER RINGS SHIFTER FORK	•	•	
WASTE-GATE ACTUATOR AUTOMATIC TRANSMISSION TORQUE CONVERTER VALVE BODY GEAR SETS MAIN AND INTERMEDIATE SHAFTS CLUTCHES AND BANDS OIL PUMP FLYWHEEL RING GEAR MANUAL TRANSMISSION HOUSING MAIN AND INTERMEDIATE SHAFTS GEAR SETS SYNCHRONIZER RINGS SHIFTER FORK BEARINGS	•	•	
WASTE-GATE ACTUATOR AUTOMATIC TRANSMISSION TORQUE CONVERTER VALVE BODY GEAR SETS MAIN AND INTERMEDIATE SHAFTS CLUTCHES AND BANDS OIL PUMP FLYWHEEL RING GEAR MANUAL TRANSMISSION HOUSING MAIN AND INTERMEDIATE SHAFTS GEAR SETS SYNCHRONIZER RINGS SHIFTER FORK BEARINGS DIFFERENTIAL			
WASTE-GATE ACTUATOR AUTOMATIC TRANSMISSION TORQUE CONVERTER VALVE BODY GEAR SETS MAIN AND INTERMEDIATE SHAFTS CLUTCHES AND BANDS OIL PUMP FLYWHEEL RING GEAR MANUAL TRANSMISSION HOUSING MAIN AND INTERMEDIATE SHAFTS GEAR SETS SYNCHRONIZER RINGS SHIFTER FORK BEARINGS DIFFERENTIAL CARRIER GEAR AND CASE			
WASTE-GATE ACTUATOR AUTOMATIC TRANSMISSION TORQUE CONVERTER VALVE BODY GEAR SETS MAIN AND INTERMEDIATE SHAFTS CLUTCHES AND BANDS OIL PUMP FLYWHEEL RING GEAR MANUAL TRANSMISSION HOUSING MAIN AND INTERMEDIATE SHAFTS GEAR SETS SYNCHRONIZER RINGS SHIFTER FORK BEARINGS DIFFERENTIAL			
WASTE-GATE ACTUATOR AUTOMATIC TRANSMISSION TORQUE CONVERTER VALVE BODY GEAR SETS MAIN AND INTERMEDIATE SHAFTS CLUTCHES AND BANDS OIL PUMP FLYWHEEL RING GEAR MANUAL TRANSMISSION HOUSING MAIN AND INTERMEDIATE SHAFTS GEAR SETS SYNCHRONIZER RINGS SHIFTER FORK BEARINGS DIFFERENTIAL CARRIER GEAR AND CASE DRIVE PINION			
WASTE-GATE ACTUATOR AUTOMATIC TRANSMISSION TORQUE CONVERTER VALVE BODY GEAR SETS MAIN AND INTERMEDIATE SHAFTS CLUTCHES AND BANDS OIL PUMP FLYWHEEL RING GEAR MANUAL TRANSMISSION HOUSING MAIN AND INTERMEDIATE SHAFTS GEAR SETS SYNCHRONIZER RINGS SHIFTER FORK BEARINGS DIFFERENTIAL CARRIER GEAR AND CASE DRIVE PINION PINION GEAR			
WASTE-GATE ACTUATOR AUTOMATIC TRANSMISSION TORQUE CONVERTER VALVE BODY GEAR SETS MAIN AND INTERMEDIATE SHAFTS CLUTCHES AND BANDS OIL PUMP FLYWHEEL RING GEAR MANUAL TRANSMISSION HOUSING MAIN AND INTERMEDIATE SHAFTS GEAR SETS SYNCHRONIZER RINGS SHIFTER FORK BEARINGS DIFFERENTIAL CARRIER GEAR AND CASE DRIVE PINION PINION GEAR DIFFERENTIAL COVER			
AUTOMATIC TRANSMISSION TORQUE CONVERTER VALVE BODY GEAR SETS MAIN AND INTERMEDIATE SHAFTS CLUTCHES AND BANDS OIL PUMP FLYWHEEL RING GEAR MANUAL TRANSMISSION HOUSING MAIN AND INTERMEDIATE SHAFTS GEAR SETS SYNCHRONIZER RINGS SHIFTER FORK BEARINGS DIFFERENTIAL CARRIER GEAR DIFFERENTIAL COVER BEARINGS			
WASTE-GATE ACTUATOR AUTOMATIC TRANSMISSION TORQUE CONVERTER VALVE BODY GEAR SETS MAIN AND INTERMEDIATE SHAFTS CLUTCHES AND BANDS OIL PUMP FLYWHEEL RING GEAR MANUAL TRANSMISSION HOUSING MAIN AND INTERMEDIATE SHAFTS GEAR SETS SYNCHRONIZER RINGS SHIFTER FORK BEARINGS DIFFERENTIAL CARRIER GEAR AND CASE DRIVE PINION PINION GEAR DIFFERENTIAL COVER BEARINGS MOUNTS			
WASTE-GATE ACTUATOR AUTOMATIC TRANSMISSION TORQUE CONVERTER VALVE BODY GEAR SETS MAIN AND INTERMEDIATE SHAFTS CLUTCHES AND BANDS OIL PUMP FLYWHEEL RING GEAR MANUAL TRANSMISSION HOUSING MAIN AND INTERMEDIATE SHAFTS GEAR SETS SYNCHRONIZER RINGS SHIFTER FORK BEARINGS DIFFERENTIAL CARRIER GEAR AND CASE DRIVE PINION PINION GEAR DIFFERENTIAL COVER BEARINGS MOUNTS TRANSAXLE			
WASTE-GATE ACTUATOR AUTOMATIC TRANSMISSION TORQUE CONVERTER VALVE BODY GEAR SETS MAIN AND INTERMEDIATE SHAFTS CLUTCHES AND BANDS OIL PUMP FLYWHEEL RING GEAR MANUAL TRANSMISSION HOUSING MAIN AND INTERMEDIATE SHAFTS GEAR SETS SYNCHRONIZER RINGS SHIFTER FORK BEARINGS DIFFERENTIAL CARRIER GEAR AND CASE DRIVE PINION PINION GEAR DIFFERENTIAL COVER BEARINGS MOUNTS TRANSAXLE HOUSING		•	
AUTOMATIC TRANSMISSION TORQUE CONVERTER VALVE BODY GEAR SETS MAIN AND INTERMEDIATE SHAFTS CLUTCHES AND BANDS OIL PUMP FLYWHEEL RING GEAR MANUAL TRANSMISSION HOUSING MAIN AND INTERMEDIATE SHAFTS GEAR SETS SYNCHRONIZER RINGS SHIFTER FORK BEARINGS DIFFERENTIAL CARRIER GEAR AND CASE DIVE PINION PINION GEAR DIFFERENTIAL COVER BEARINGS MOUNTS TRANSAXLE HOUSING MAIN SHAFTS		•	
AUTOMATIC TRANSMISSION TORQUE CONVERTER VALVE BODY GEAR SETS MAIN AND INTERMEDIATE SHAFTS CLUTCHES AND BANDS OIL PUMP FLYWHEEL RING GEAR MANUAL TRANSMISSION HOUSING MAIN AND INTERMEDIATE SHAFTS GEAR SETS SYNCHRONIZER RINGS SHIFTER FORK BEARINGS DIFFERENTIAL CARRIER GEAR AND CASE DRIVE PINION PINION GEAR DIFFERENTIAL COVER BEARINGS MOUNTS TRANSAXLE HOUSING MAIN SHAFTS CROWN AND PINION		•	
AUTOMATIC TRANSMISSION TORQUE CONVERTER VALVE BODY GEAR SETS MAIN AND INTERMEDIATE SHAFTS CLUTCHES AND BANDS OIL PUMP FLYWHEEL RING GEAR MANUAL TRANSMISSION HOUSING MAIN AND INTERMEDIATE SHAFTS GEAR SETS SYNCHRONIZER RINGS SHIFTER FORK BEARINGS DIFFERENTIAL CARRIER GEAR AND CASE DRIVE PINION PINION GEAR MOUNTS TRANSAXLE HOUSING MAIN SHAFTS CROWN AND PINION PINION GEARS AND BEARINGS		•	
AUTOMATIC TRANSMISSION TORQUE CONVERTER VALVE BODY GEAR SETS MAIN AND INTERMEDIATE SHAFTS CLUTCHES AND BANDS OIL PUMP FLYWHEEL RING GEAR MANUAL TRANSMISSION HOUSING MAIN AND INTERMEDIATE SHAFTS GEAR SETS SYNCHRONIZER RINGS SHIFTER FORK BEARINGS DIFFERENTIAL CARRIER GEAR AND CASE DRIVE PINION PINION GEAR DIFFERENTIAL COVER BEARINGS MOUNTS TRANSAXLE HOUSING MAIN SHAFTS CROWN AND PINION PINION GEARS AND BEARINGS TRANSFER CASE TRANSFER CASE		•	
AUTOMATIC TRANSMISSION TORQUE CONVERTER VALVE BODY GEAR SETS MAIN AND INTERMEDIATE SHAFTS CLUTCHES AND BANDS OIL PUMP FLYWHEEL RING GEAR MANUAL TRANSMISSION HOUSING MAIN AND INTERMEDIATE SHAFTS GEAR SETS SYNCHRONIZER RINGS SHIFTER FORK BEARINGS DIFFERENTIAL CARRIER GEAR AND CASE DRIVE PINION PINION GEAR MOUNTS TRANSAXLE HOUSING MAIN SHAFTS CROWN AND PINION PINION GEARS AND BEARINGS TRANSFER CASE HOUSING		•	
AUTOMATIC TRANSMISSION TORQUE CONVERTER VALVE BODY GEAR SETS MAIN AND INTERMEDIATE SHAFTS CLUTCHES AND BANDS OIL PUMP FLYWHEEL RING GEAR MANUAL TRANSMISSION HOUSING MAIN AND INTERMEDIATE SHAFTS GEAR SETS SYNCHRONIZER RINGS SHIFTER FORK BEARINGS DIFFERENTIAL CARRIER GEAR AND CASE DRIVE PINION PINION GEAR DIFFERENTIAL COVER BEARINGS MOUNTS TRANSAXLE HOUSING MAIN SHAFTS CROWN AND PINION PINION GEARS AND BEARINGS TRANSFER CASE HOUSING MAIN SHAFTS		•	



If certain conditions are met, 2 to 4 year warranty holders would be eligible for an extension to a term equal to the length of the one originally purchased. (See Agreement For Full Terms and Conditions).

DAY TIME RUNNING LIGHTS MODULE

ECM/PCM

	*	****	TH ***
AIR CONDITIONER			
COMPRESSOR	•	•	•
COMPRESSOR CLUTCH AND PULLEY CONDENSER AND EVAPORATOR	•	•	•
ORIFICE TUBE	•	•	
Lines	•	•	•
ACCUMULATOR	•	•	•
DRYER	•	•	•
HIGH AND LOW PRESSURE CUTOFF SWITCHES	•	•	•
SEALS AND GASKETS GASKETS AND OIL SEALS ON COVERED PARTS ENUMERATED IN	•	•	•
THE WARRANTY AGREEMENT ELECTRIC SYSTEM			
AUTOMATIC TEMPERATURE CONTROL/PROGRAMMER-DISPLAY	•	•	•
UNIT HEATER BLOWER SWITCH			
MAIN DASH BOARD DIGITAL DISPLAY CLUSTER	•	•	
Power Door Locks Switches	•		
ALTERNATOR	•		
WINDSHIELD WASHER PUMP	•		
REAR WINDOW WASHER PUMP	•	•	•
FRONT AND REAR WIPER MOTORS	•	•	•
FRONT AND REAR WIPER SWITCHES	•	•	•
FRONT AND REAR WIPER REGULATION AND GEARING	•	•	•
POWER WINDOWS SWITCHES	•	•	•
Power Seats Switches	•	•	•
SIDE-VIEW MIRRORS SWITCHES	•	•	•
Power Sunroof Switch	•	•	•
HEADLIGHTS SWITCH	•	•	•
HEADLAMP SWITCH	•	•	•
Turn Signals Switch	•	•	•
Cruise Control Switch	•	•	•
REAR WINDOW DEFROSTER SWITCH	•	•	
EMERGENCY WARNING FLASHERS SWITCH	•	•	•
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION	•	•	•
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER	•	•	•
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER IGNITION ELECTRONIC MODULE	•	•	•
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER	•	•	•
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER IGNITION ELECTRONIC MODULE FUEL INJECTION SYSTEM	•	•	•
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER IGNITION ELECTRONIC MODULE FUEL INJECTION SYSTEM FUEL INJECTORS	•	•	•
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER IGNITION ELECTRONIC MODULE FUEL INJECTION SYSTEM FUEL INJECTORS FUEL PUMP AND METAL GAS LINKS	•	•	•
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER IGNITION ELECTRONIC MODULE FUEL INJECTION SYSTEM FUEL INJECTORS FUEL PUMP AND METAL GAS LINKS FUEL TANK AND FUEL GAUGE	•	•	•
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER IGNITION ELECTRONIC MODULE FUEL INJECTION SYSTEM FUEL INJECTORS FUEL PUMP AND METAL GAS LINKS FUEL TANK AND FUEL GAUGE FUEL PRESSURE REGULATOR	•	•	•
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER IGNITION ELECTRONIC MODULE FUEL INJECTION SYSTEM FUEL INJECTORS FUEL PUMP AND METAL GAS LINKS FUEL TANK AND FUEL GAUGE FUEL PRESSURE REGULATOR FUEL RAILS	•	•	•
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER IGNITION ELECTRONIC MODULE FUEL INJECTION SYSTEM FUEL INJECTORS FUEL PUMP AND METAL GAS LINKS FUEL TANK AND FUEL GAUGE FUEL PRESSURE REGULATOR FUEL RAILS BRAKES MASTER CYLINDER BRAKE BOOSTER		•	•
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER IGNITION ELECTRONIC MODULE FUEL INJECTION SYSTEM FUEL INJECTORS FUEL PUMP AND METAL GAS LINKS FUEL TANK AND FUEL GAUGE FUEL PRESSURE REGULATOR FUEL RAILS BRAKES MASTER CYLINDER BRAKE BOOSTER WHEEL CYLINDERS	•	•	•
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER IGNITION ELECTRONIC MODULE FUEL INJECTION SYSTEM FUEL INJECTORS FUEL PUMP AND METAL GAS LINKS FUEL TANK AND FUEL GAUGE FUEL PRESSURE REGULATOR FUEL RAILS BRAKES MASTER CYLINDER BRAKE BOOSTER WHEEL CYLINDERS BRAKE SPLIT VALVE		•	
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER IGNITION ELECTRONIC MODULE FUEL INJECTION SYSTEM FUEL INJECTORS FUEL PUMP AND METAL GAS LINKS FUEL TANK AND FUEL GAUGE FUEL PRESSURE REGULATOR FUEL RAILS BRAKES MASTER CYLINDER BRAKE BOOSTER WHEEL CYLINDERS BRAKE SPLIT VALVE DISC BRAKE CALLIPERS	•		
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER IGNITION ELECTRONIC MODULE FUEL INJECTION SYSTEM FUEL INJECTORS FUEL PUMP AND METAL GAS LINKS FUEL TANK AND FUEL GAUGE FUEL RESSURE REGULATOR FUEL RAILS BRAKES MASTER CYLINDER BRAKE BOOSTER WHEEL CYLINDERS BRAKE SPLIT VALVE DISC BRAKE CALLIPERS FLEXIBLE HYDRAULIC BRAKE LINES AND FITTINGS			
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER IGNITION ELECTRONIC MODULE FUEL INJECTION SYSTEM FUEL INJECTION SYSTEM FUEL PUMP AND METAL GAS LINKS FUEL TANK AND FUEL GAUGE FUEL PRESSURE REGULATOR FUEL RAILS BRAKES MASTER CYLINDER BRAKE BOOSTER WHEEL CYLINDERS BRAKE SPLIT VALVE DISC BRAKE CALLIPERS FLEXIBLE HYDRAULIC BRAKE LINES AND FITTINGS OIL SEALS			
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER IGNITION ELECTRONIC MODULE FUEL INJECTION SYSTEM FUEL INJECTORS FUEL PUMP AND METAL GAS LINKS FUEL TANK AND FUEL GAUGE FUEL PRESSURE REGULATOR FUEL RAILS BRAKES MASTER CYLINDER BRAKE BOOSTER WHEEL CYLINDERS BRAKE SPUT VALVE DISC BRAKE CALLIPERS FLEXIBLE HYDRAULIC BRAKE LINES AND FITTINGS OIL SEALS COMBINATION VALVE			
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER IGNITION ELECTRONIC MODULE FUEL INJECTION SYSTEM FUEL INJECTION SYSTEM FUEL PUMP AND METAL GAS LINKS FUEL PUMP AND FUEL GAUGE FUEL PRESSURE REGULATOR FUEL RAILS BRAKES MASTER CYLINDER BRAKE BOOSTER WHEEL CYLINDERS BRAKE SPLIT VALVE DISC BRAKE CALLIPERS FLEXIBLE HYDRAULIC BRAKE LINES AND FITTINGS OIL SEALS COMBINATION VALVE VACUUM ASSIST BOOSTER PUMP			
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER IGNITION ELECTRONIC MODULE FUEL INJECTION SYSTEM FUEL INJECTION SYSTEM FUEL PUMP AND METAL GAS LINKS FUEL PUMP AND FUEL GAUGE FUEL PRESSURE REGULATOR FUEL RAILS BRAKES MASTER CYLINDER BRAKE BOOSTER WHEEL CYLINDERS BRAKE SPLIT VALVE DISC BRAKE CALLIPERS FLEXIBLE HYDRAULIC BRAKE LINES AND FITTINGS OIL SEALS COMBINATION VALVE VACUUM ASSIST BOOSTER PUMP PARKING BRAKE LINKAGE AND CABLES			
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER IGNITION ELECTRONIC MODULE FUEL INJECTION SYSTEM FUEL INJECTORS FUEL PUMP AND METAL GAS LINKS FUEL TANK AND FUEL GAUGE FUEL PRESSURE REGULATOR FUEL RAILS BRAKES MASTER CYLINDER BRAKE BOOSTER WHEEL CYLINDERS BRAKE SPLIT VALVE DISC BRAKE CALLIPERS FLEXIBLE HYDRAULIC BRAKE LINES AND FITTINGS OIL SEALS COMBINATION VALVE VACUUM ASSIST BOOSTER PUMP PARKING BRAKE LINKAGE AND CABLES ABS BRAKES/TRACTION CONTROL SYSTEM (**)			
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER IGNITION ELECTRONIC MODULE FUEL INJECTION SYSTEM FUEL INJECTION SYSTEM FUEL PUMP AND METAL GAS LINKS FUEL PUMP AND FUEL GAUGE FUEL PRESSURE REGULATOR FUEL RAILS BRAKES MASTER CYLINDER BRAKE BOOSTER WHEEL CYLINDERS BRAKE SPLIT VALVE DISC BRAKE CALLIPERS FLEXIBLE HYDRAULIC BRAKE LINES AND FITTINGS OIL SEALS COMBINATION VALVE VACUUM ASSIST BOOSTER PUMP PARKING BRAKE LINKAGE AND CABLES			
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER GONITION ELECTRONIC MODULE FUEL INJECTION SYSTEM FUEL INJECTION SYSTEM FUEL PUMP AND METAL GAS LINKS FUEL PUMP AND METAL GAUGE FUEL PRESSURE REGULATOR FUEL RAILS BRAKES MASTER CYLINDER BRAKE BOOSTER WHEEL CYLINDERS BRAKE SPLIT VALVE DISC BRAKE CALLIPERS FLEXIBLE HYDRAULIC BRAKE LINES AND FITTINGS OIL SEALS COMBINATION VALVE VACUUM ASSIST BOOSTER PUMP PARKING BRAKE LINKAGE AND CABLES ABS BRAKES/TRACTION CONTROL SYSTEM (ABS/TCS PRESSURE REGULATOR			
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER GONITION ELECTRONIC MODULE FUEL INJECTION SYSTEM FUEL INJECTORS FUEL PUMP AND METAL GAS LINKS FUEL PASSURE REGULATOR FUEL PRESSURE REGULATOR FUEL RAILS BRAKES MASTER CYLINDER BRAKE BOOSTER WHEEL CYLINDERS BRAKE SPLIT VALVE DISC BRAKE CALLIPERS FLEXIBLE HYDRAULIC BRAKE LINES AND FITTINGS OIL SEALS COMBINATION VALVE VACUUM ASSIST BOOSTER PUMP PARKING BRAKE LINKAGE AND CABLES ABS BRAKES/TRACTION CONTROL SYSTEM (ABS/TCS PRESSURE REGULATOR PRESSURE ACCUMULATOR			
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER IGNITION ELECTRONIC MODULE FUEL INJECTION SYSTEM FUEL INJECTION SYSTEM FUEL PUMP AND METAL GAS LINKS FUEL PARESURE REGULATOR FUEL RAILS BRAKES MASTER CYLINDER BRAKE BOOSTER WHEEL CYLINDERS BRAKE SPLIT VALVE DISC BRAKE CALLIPERS FLEXIBLE HYDRAULIC BRAKE LINES AND FITTINGS OIL SEALS COMBINATION VALVE VACUUM ASSIST BOOSTER PUMP PARKING BRAKE LINKAGE AND CABLES ABS BRAKES/TRACTION CONTROL SYSTEM (ABS/TCS PRESSURE REGULATOR PRESSURE ACCUMULATOR HYDRAULIC PUMP HYDRAULIC PRESSURE VALVES			
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER IGNITION ELECTRONIC MODULE FUEL INJECTION SYSTEM FUEL INJECTION SYSTEM FUEL PUMP AND METAL GAS LINKS FUEL PARESURE REGULATOR FUEL RAILS BRAKES MASTER CYLINDER BRAKE BOOSTER WHEEL CYLINDERS BRAKE SPLIT VALVE DISC BRAKE CALLIPERS FLEXIBLE HYDRAULIC BRAKE LINES AND FITTINGS OIL SEALS COMBINATION VALVE VACUUM ASSIST BOOSTER PUMP PARKING BRAKE LINKAGE AND CABLES ABS BRAKES/TRACTION CONTROL SYSTEM (ABS/TCS PRESSURE REGULATOR PRESSURE ACCUMULATOR HYDRAULIC PUMP HYDRAULIC PRESSURE VALVES			
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER IGNITION ELECTRONIC MODULE FUEL INJECTION SYSTEM FUEL INJECTORS FUEL PUMP AND METAL GAS LINKS FUEL PARESURE REGULATOR FUEL RAILS BRAKES MASTER CYLINDER BRAKE BOOSTER WHEEL CYLINDERS BRAKE SPLIT VALVE DISC BRAKE CALLIPERS FLEXIBLE HYDRAULIC BRAKE LINES AND FITTINGS OIL SEALS COMBINATION VALVE VACUUM ASSIST BOOSTER PUMP PARKING BRAKE LINKAGE AND CABLES ABS BRAKES/TRACTION CONTROL SYSTEM (ABS/TCS PRESSURE REGULATOR PRESSURE ACCUMULATOR HYDRAULIC PRESSURE VALVES POWER STEERING RACK-AND-PINION GEAR			
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER IGNITION ELECTRONIC MODULE FUEL INJECTION SYSTEM FUEL INJECTORS FUEL PUMP AND METAL GAS LINKS FUEL PARESURE REGULATOR FUEL RAILS BRAKES MASTER CYLINDER BRAKE BOOSTER WHEEL CYLINDERS BRAKE SPLIT VALVE DISC BRAKE CALLIPERS FLEXIBLE HYDRAULIC BRAKE LINES AND FITTINGS OIL SEALS COMBINATION VALVE VACUUM ASSIST BOOSTER PUMP PARKING BRAKE LINKAGE AND CABLES ABS BRAKES/TRACTION CONTROL SYSTEM (ABS/TCS PRESSURE REGULATOR PRESSURE ACCUMULATOR HYDRAULIC PRESSURE VALVES POWER STEERING RACK-AND-PINION GEAR			
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER IGNITION ELECTRONIC MODULE FUEL INJECTION SYSTEM FUEL INJECTORS FUEL PUMP AND METAL GAS LINKS FUEL PRESSURE REGULATOR FUEL RAILS BRAKES MASTER CYLINDER BRAKE BOOSTER WHEEL CYLINDERS BRAKE SPLIT VALVE DISC BRAKE CALLIPERS FLEXIBLE HYDRAULIC BRAKE LINES AND FITTINGS OIL SEALS COMBINATION VALVE VACUUM ASSIST BOOSTER PUMP PARKING BRAKE LINKAGE AND CABLES ABS BRAKES/TRACTION CONTROL SYSTEM (** ABS/TCS PRESSURE REGULATOR PRESSURE ACCUMULATOR HYDRAULIC PUMP HYDRAULIC PUMP HYDRAULIC PRESSURE VALVES POWER STEERING RACK-AND-PINION GEAR POWER STEERING PUMP			
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER IGNITION ELECTRONIC MODULE FUEL INJECTION SYSTEM FUEL INJECTORS FUEL PUMP AND METAL GAS LINKS FUEL PASSURE REGULATOR FUEL RAILS BRAKES MASTER CYLINDER BRAKE BOOSTER WHEEL CYLINDERS BRAKE SPLIT VALVE DISC BRAKE CALLIPERS FLEXIBLE HYDRAULIC BRAKE LINES AND FITTINGS OIL SEALS COMBINATION VALVE VACUUM ASSIST BOOSTER PUMP PARKING BRAKE LINKAGE AND CABLES ABS BRAKES/TRACTION CONTROL SYSTEM (ABS/TCS PRESSURE REGULATOR HYDRAULIC PUMP HYDRAULIC PUMP HYDRAULIC PUMP HYDRAULIC PUSSURE VALVES POWER STEERING RACK-AND-PINION GEAR POWER STEERING PUMP TIE ROD ENDS			
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER IGNITION ELECTRONIC MODULE FUEL INJECTION SYSTEM FUEL INJECTION SYSTEM FUEL PUMP AND METAL GAS LINKS FUEL TANK AND FUEL GAUGE FUEL PRESSURE REGULATOR FUEL RAILS BRAKES MASTER CYLINDER BRAKE BOOSTER WHEEL CYLINDERS BRAKE SPLIT VALVE DISC BRAKE CALLIPERS FLEXIBLE HYDRAULIC BRAKE LINES AND FITTINGS OIL SEALS COMBINATION VALVE VACUUM ASSIST BOOSTER PUMP PARKING BRAKE LINKAGE AND CABLES ABS BRAKES/TRACTION CONTROL SYSTEM (ABS/TCS PRESSURE REGULATOR HYDRAULIC PUMP HYDRAULIC PUMP HYDRAULIC PUMP HYDRAULIC PRESSURE VALVES POWER STEERING RACK-AND-PINION GEAR POWER STEERING PUMP TIE ROD ENDS ELECTRIC SYSTEM EXTENDED ELECTRIC WINDOW MOTORS AND REGULATION AND GEARING			
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER IGNITION ELECTRONIC MODULE FUEL INJECTION SYSTEM FUEL INJECTORS FUEL PUMP AND METAL GAS LINKS FUEL PRESSURE REGULATOR FUEL RAILS BRAKES MASTER CYLINDER BRAKE BOOSTER WHEEL CYLINDERS BRAKE SPLIT VALVE DISC BRAKE CALLIPERS FLEXIBLE HYDRAULIC BRAKE LINES AND FITTINGS OIL SEALS COMBINATION VALVE VACUUM ASSIST BOOSTER PUMP PARKING BRAKE LINKAGE AND CABLES ABS BRAKES/TRACTION CONTROL SYSTEM (** ABS/TCS PRESSURE REGULATOR HYDRAULIC PUMP HYDRAULIC PUMP HYDRAULIC PRESSURE VALVES POWER STEERING RACK-AND-PINION GEAR POWER STEERING PUMP ELECTRIC SYSTEM EXTENDED ELECTRIC SEAT MOTORS AND REGULATION AND GEARING ELECTRIC SEAT MOTORS AND REGULATION GEARING ELECTRIC SEAT MOTORS AND REGULATION GEARING ELECTRIC SEAT MOTORS AND REGULATION AND GEARING ELECTRIC SEAT MOTORS AND REGULATION GEARING			
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER GONITION ELECTRONIC MODULE FUEL INJECTION SYSTEM FUEL INJECTORS FUEL PUMP AND METAL GAS LINKS FUEL PRESSURE REGULATOR FUEL RAILS BRAKES MASTER CYLINDER BRAKE BOOSTER WHEEL CYLINDERS BRAKE SPLIT VALVE DISC BRAKE CALLIPERS FLEXIBLE HYDRAULIC BRAKE LINES AND FITTINGS OIL SEALS COMBINATION VALVE VACUUM ASSIST BOOSTER PUMP PARKING BRAKE LINKAGE AND CABLES ABS BRAKES/TRACTION CONTROL SYSTEM (ABS/TCS PRESSURE REGULATOR HYDRAULIC PUMP HYDRAULIC PUMP HYDRAULIC PRESSURE VALVES POWER STEERING RACK-AND-PINION GEAR POWER STEERING PUMP ELECTRIC SYSTEM EXTENDED ELECTRIC SYSTEM EXTENDED ELECTRIC SEAT MOTORS AND REGULATION GEARING ELECTRIC REAR-VIEW MIRROR MOTOR HEATER BLOWER			
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER IGNITION ELECTRONIC MODULE FUEL INJECTION SYSTEM FUEL INJECTORS FUEL PUMP AND METAL GAS LINKS FUEL TANK AND FUEL GAUGE FUEL PRESSURE REGULATOR FUEL RAILS BRAKES MASTER CYLINDER BRAKE BOOSTER WHEEL CYLINDERS BRAKE SPLIT VALVE DISC BRAKE CALLIPERS FLEXIBLE HYDRAULIC BRAKE LINES AND FITTINGS OIL SEALS COMBINATION VALVE VACUUM ASSIST BOOSTER PUMP PARKING BRAKE LINKAGE AND CABLES ABS BRAKES/TRACTION CONTROL SYSTEM (ABS/TCS PRESSURE REGULATOR HYDRAULIC PUMP HYDRAULIC PUMP HYDRAULIC PUMP HYDRAULIC PRESSURE VALVES POWER STEERING RACK-AND-PINION GEAR POWER STEERING PUMP ELECTRIC SYSTEM EXTENDED ELECTRIC SYSTEM EXTENDED ELECTRIC SEAT MOTORS AND REGULATION AND GEARING ELECTRIC SEATS MOTORS AND REGULATION AND GEARING ELECTRIC REAR-VIEW MIRROR MOTOR HEATER BLOWER POWER SEATS MOTORS AND REGULATION AND GEARING			
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER IGNITION ELECTRONIC MODULE FUEL INJECTION SYSTEM FUEL INJECTORS FUEL PUMP AND METAL GAS LINKS FUEL TANK AND FUEL GAUGE FUEL RAILS BRAKES MASTER CYLINDER BRAKE BOOSTER WHEEL CYLINDERS BRAKE SPLIT VALVE DISC BRAKE CALLIPERS FLEXIBLE HYDRAULIC BRAKE LINES AND FITTINGS OIL SEALS COMBINATION VALVE VACUUM ASSIST BOOSTER PUMP PARKING BRAKE LINKAGE AND CABLES ABS BRAKES/TRACTION CONTROL SYSTEM (ABS/TCS PRESSURE REGULATOR HYDRAULIC PUMP HYDRAULIC PUMP HYDRAULIC PRESSURE VALVES POWER STEERING RACK-AND-PINION GEAR POWER STEERING ELECTRIC SYSTEM EXTENDED ELECTRIC SYSTEM EXTENDED ELECTRIC SEAT MOTORS AND REGULATION AND GEARING ELECTRIC SEAT MOTORS AND REGULATION AND GEARING ELECTRIC REAR-VIEW MIRROR MOTOR HEATER BLOWER POWER SEATS MOTORS AND REGULATION AND GEARING ELECTRIC PUMP HYDER SEATS MOTORS AND REGULATION AND GEARING ELECTRIC REAR-VIEW MIRROR MOTOR HEATER BLOWER POWER SEATS MOTORS AND REGULATION AND GEARING ELECTRIC PUMP POWER SEATS MOTORS AND REGULATION AND GEARING ELECTRIC REAR-VIEW MIRROR MOTOR POWER SEATS MOTORS AND REGULATION AND GEARING SIDE-VIEW MIRRORS MOTORS			
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER IGNITION ELECTRONIC MODULE FUEL INJECTION SYSTEM FUEL INJECTORS FUEL PUMP AND METAL GAS LINKS FUEL TANK AND FUEL GAUGE FUEL RAILS BRAKES MASTER CYLINDER BRAKE BOOSTER WHEEL CYLINDERS BRAKE SPLIT VALVE DISC BRAKE CALLIPERS FLEXIBLE HYDRAULIC BRAKE LINES AND FITTINGS OIL SEALS COMBINATION VALVE VACUUM ASSIST BOOSTER PUMP PARKING BRAKE LINKAGE AND CABLES ABS BRAKES/TRACTION CONTROL SYSTEM (*ABS/TCS PRESSURE REGULATOR**) PRESSURE ACCUMULATOR HYDRAULIC PUMP HYDRAULIC PUMP HYDRAULIC PRESSURE VALVES POWER STEERING RACK-AND-PINION GEAR POWER STEERING ELECTRIC SYSTEM EXTENDED ELECTRIC SYSTEM EXTENDED ELECTRIC SYSTEM EXTENDED ELECTRIC REAR-VIEW MIRROR MOTOR HEATER BLOWER POWER SEATS MOTORS AND REGULATION AND GEARING SIDE-VIEW MIRRORS MOTORS POWER SUNROOF MOTOR			
EMERGENCY WARNING FLASHERS SWITCH ELECTRONIC IGNITION STARTER IGNITION ELECTRONIC MODULE FUEL INJECTION SYSTEM FUEL INJECTORS FUEL PUMP AND METAL GAS LINKS FUEL TANK AND FUEL GAUGE FUEL RAILS BRAKES MASTER CYLINDER BRAKE BOOSTER WHEEL CYLINDERS BRAKE SPLIT VALVE DISC BRAKE CALLIPERS FLEXIBLE HYDRAULIC BRAKE LINES AND FITTINGS OIL SEALS COMBINATION VALVE VACUUM ASSIST BOOSTER PUMP PARKING BRAKE LINKAGE AND CABLES ABS BRAKES/TRACTION CONTROL SYSTEM (ABS/TCS PRESSURE REGULATOR PRESSURE ACCUMULATOR HYDRAULIC PUMP HYDRAULIC PRESSURE VALVES POWER STEERING RACK-AND-PINION GEAR POWER STEERING ELECTRIC SYSTEM EXTENDED ELECTRIC SYSTEM EXTENDED ELECTRIC SEAT MOTORS AND REGULATION AND GEARING ELECTRIC SEAT MOTORS AND REGULATION AND GEARING POWER SEATS MOTORS AND REGULATION AND GEARING ELECTRIC REAR-VIEW MIRROR MOTOR HEATER BLOWER POWER SEATS MOTORS AND REGULATION AND GEARING ELECTRIC PUWP MIRROR MOTOR POWER SEATS MOTORS AND REGULATION AND GEARING ELECTRIC SEAT MOTORS AND REGULATION AND GEARING ELECTRIC WINDOW MIRROR MOTOR			

	**	****	MACAGAR HI
FRONT SUSPENSION			
BALL JOINTS		•	•
UPPER AND LOWER SUSPENSION ARMS BUSHINGS		•	•
HUB AND WHEEL BEARINGS		•	•
REAR SUSPENSION			
BALL JOINTS UPPER AND LOWER SUSPENSION ARMS		•	•
LINKS & BUSHINGS		•	
HUB AND WHEEL BEARINGS		•	•
DRIVELINE			
DRIVE SHAFT DRIVE AXLE		•	
Universal Joints		•	•
COOLING SYSTEM			
WATER PUMP RADIATOR		•	•
THERMOSTAT		•	•
COOLING FLUID OVERFLOW TANK		•	•
POWERTRAIN EXTENDED			
VALVE COVER			
VARIABLE VALVE TIMING MOTOR			
DIESEL ADBLUE HEATER AND PUMP (EXCLUDING LINES)			•
OIL PAN			•
INTAKE AND EXHAUST VANOS SOLENOIDS			•
WASTEGATE CONTROLLER			•
ENTERTAINMENT SYSTEM			
LCD SCREEN			•
RF MODULE			•
Power Inverter			•
DVD PLAYER / CD PLAYER / CD CHANGER			•
SPEAKERS			•
NAVIGATION SYSTEM			
NAVIGATION DISPLAY UNIT			•
NAVIGATION CONTROL MODULE			
NAVIGATION SYSTEM WIRING HARNESS			•
PHONE SYSTEMS			
BLUETOOTH MODULE			•
Microphone/Speakers			
AIRBAG ELECTRONICS			
AIRBAG MODULE AIRBAG CABLE/CONTACT COIL			
COOLING SYSTEM EXTENDED			
Oil Cooler			
HEATER CORE			
SENSORS			
AIRBAG SENSOR(s)			
ABS ELECTRONIC WHEEL SENSOR			
O2 Sensor			
NOX Sensor			
Turbo-Compressor Sensors			
AUTOMATIC TRANSMISSION ELECTRONIC CONTROL SENSORS			
ELECTRONIC IGNITION SENSORS			
DAY TIME RUNNING LIGHTS SENSORS			
HEADLIGHT SENSORS			
BACK UP SENSORS HVPDID / ELECTRIC VEHICLE COMPONENTS			
HYBRID/ELECTRIC VEHICLE COMPONENTS BATTERY CHARGER			
BATTERY CHARGER ELECTRIC MOTOR			
GENERATORS			
HIGH VOLTAGE CABLES			
Power Controller			•
Convertor/Inverter			
trip interruption			

trip interruption

(INCLUDED IN ALL PLANS)

A max of \$100.00/day for a max of 5 days per occurrence will be reimbursed for expenses at a hotel or motel when a breakdown or a mechanical failure is covered by the warranty. (See Warranty Agreement for Full Details.)

rental allowance

(INCLUDED IN ALL PLANS)

\$40.00 per day, for a maximum of 5 days per claim repair occurrence. (See Warranty Agreement for Full Details)

